USER MANUAL

SYTECH®

When technology turns to art

HAND MIXER

SY-MZ25

WELCOME

Dear Customer,
Welcome to Sytech! Thank you for purchasing the new Hand Mixer SY-MZ25. Please read this manual carefully before operating your product and pay close attention to the precautions which are mentioned below. Store this user manual in a safe place for future reference. We are sure that this new Hand Mixer will satisfy your needs.

PARTS OF THE SY-MZ25

1. Control knob
2. Turbo button
3. Dough hook
4. Beater
5. Eject handle
6. Housing
7. Handle cover

IMPORTANT SAFETY RECOMMENDATION:

1. Read the instructions carefully before using your appliance for the first time.
2. Never leave the appliance within reach of children. The use of this appliance by young children or by disabled people must always be supervised.
3. Don’t use outdoors. Your appliance is intended solely for domestic use and within the home.
4. Always unplug your appliance once you have finished using it and before cleaning it.
5. Don’t use your appliance if it has been damaged. You should contact Sytech Service center for further assistance.
6. Never place the appliance, the power cable or any other part in water or any other liquid.
7. If the power cable or the plug is damaged, don’t use your appliance. To avoid any risk, these must be replaced by an approved service centre.
8. To avoid any kind of danger, do not repair or replace parts of the unit by yourself, always contact an authorized dealer.
9. Never touch the beaters and dough hooks. When the appliance is operating, don’t allow long hair, Scarves etc. to hang down over the accessories when they are in operation.
10. Unplug the appliance before handing it in any way (fitting and removed of accessories.)
11. Never fit accessories with different functions at the same time. (Dough hooks and beater etc.)
12. The power cable must never be close to any heat source and must not be placed on or near sharp edges.

13. The appliance is not to be used by children or persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction.
14. Before using your appliance for the first time, clean the various accessories of your appliance carefully.

HOW TO USE THE APPLIANCE

1. Insert the beaters or hooks until they are locked into place. Pay close attention to the markings on the accessories and the markings on the openings in order to insert the accessories properly.
2. Plug in the appliance.
3. Place the ingredients in an appropriate container.
4. Place the beaters into the container and start the appliance by turning the control knob to the right.
5. Turn the control knob to the right to select between between speed levels “1”~ “5”.
6. When you have finished using it, place the control knob to position “0”.
7. Unplug the appliance.
8. Eject the beaters by pushing the eject handle and store the unit in a safe place.

MIXING GUIDE

SPEED	DESCRIPTION
1-2	For mixing dry ingredients with liquids, folding whipped egg whites and cream into mixtures, stirring gravies and sauces and mashing vegetables.
3-4	For mixing cake mixes, puddings or batters. For creaming together ingredients.
5	For whipping cream, evaporated or powdered milk, egg whites or whole eggs. For mixing minced meat or kneading heavy dough.
TURBO	Same speed as level “5”

CAUTION:

1. After 5 minutes of continuous use, allow the unit to rest a few minutes before the next use.
2. Do not operate more than 5 minutes at one time as the unit may overheat.

CLEANING THE UNIT

1. Unplug the appliance.
2. Clean the body of the appliance using only a damp cloth.
3. Clean the beaters or dough hooks under running water or in the dishwasher. Rinse and dry before storing away. CAUTION: The attachments are very sharp!
4. On completion of using your appliance it is strongly recommended that you clean the accessories immediately. This will remove any remaining food from the accessories and will make cleaning easier.

SPECIFICATIONS

Hand Mixer with 2 attachments
5 Speeds + Turbo button
2 Kneading spirals
2 Rods for mixing/beating
Ejector for releasing the accessories
Safety lock – beaters and hooks will not be ejected during use
Power Supply: 220-240V / 50-60Hz
Power: 250W

DECLARATION OF CONFORMITY

Manufacturer Name: Satyatrade S. L.
Address: Pol.Ind.La Raya. C/ Guadalquivir, 2.
Camarma de Esteruelas, 28816 Madrid
Tel: 902 430 967
Fax: 91 8864285
NIF: B83254763
Manufacturing country: China
Sytech® SY-MZ25 complies with the following directives:

EMC Standard: Directive 2004/108 CE

LVD Standard: Directive 2006/95/CE

ROHS Standard: 2011/65/EU Restriction of Hazardous Substances

Signed: Ajeet Nebhwani Utamchandani
Sole Administrator